

STEREO SYSTEM RACK

SRC-502 © /552 ©

KENWOOD

KENWOOD CORPORATION

ASSEMBLY INSTRUCTIONS


©PRINTED IN U.S.A. B61-0519-00(K)(TCA)
R0256

IMPORTANT:

- Before operating your new KENWOOD product, read through this assembly manual carefully to get the most out of it.
- Save this assembly instructions.

Before Assembling

- Be sure to check that all parts are accounted for before disposing of the packing case.
- A Phillips screwdriver and a mallet are required for assembling.
- Be careful not to damage the floor and rack.



Notes on Assembling

- During assembling, be sure to verify the numbers stamped on the boards.
- Mount the rear panel after assembling the side panel on the bottom shelf at a right angle.
- When mounting the top shelf and kick plate on the side panel, use glue for adhesive. Be sure to remove any excess glue before it dries.
- If the amplifier wobbles when its key switches are pressed, insert a wooden dowel into the hole on the side panel and fix the rear of the amplifier.

Handling Precautions

- Tempered glass is used for the glass doors for providing sufficient strength. However, pay attention not to apply excessive force or to scratch the doors. Cracking or breaking of the glass may occur.
- When moving the cabinet, remove all the components from the rack before carrying the cabinet. Also do not grasp the top shelf when carrying.
- To allow head radiation from the components, leave a space of 4 inches between the cabinet and wall.
- Do not place the cabinet in a location subject to direct sunlight or near a heater, an air-conditioner, or a place with high humidity.

IMPORTANT SAFEGUARDS

Caution : Read this page carefully to keep your safety.

Please read all of the safety and operating instructions before operating this unit. For best results, follow all warnings placed on the unit and adhere to the operating and use instructions. These safety and operating instructions should be retained for future reference.


1. **Suffocation** — After taking the unit out of the polyethylene bag, be sure to dispose of the polyethylene bag out of the reach of children. Otherwise, they may play with the bag, which could cause hazard of suffocation.




2. **Water and moisture** — Do not place a liquid container, such as a vase and water basin, on the unit. Also avoid installing the unit in a place subject to dampness.



3. **Heat** — Do not install the unit near a source of heat, such as a heater, or under direct sunlight.




4. **Impact** — Avoid placing the unit on an unstable surface. Install it on a horizontal surface not subject to excessive dirt or vibrations.



5. **Modification** — Do not attempt to open or modify the unit, for this could cause fire hazard or malfunction.



6. **Cleaning** — Do not use thinner, benzine or alcohol. When cleaning the unit, wipe with a soft, dry cloth.



















7. **Abnormal smell** — In the event the unit generates smoke or abnormal smell, immediately switch the power OFF and unplug the power cord. After this, please contact your dealer or nearest service station as soon as possible.


POWER OFF!





PARTS LIST MODEL SRC-502 © /552 ©
ASSEMBLY INSTRUCTIONS

Item	Description	Q.T.Y.	Part No.
①		4	SRC-502 © S0033
②		16	SRC-552 © S0035
③		16	S0034
④		1	M0018
⑤		2	P0054
⑥		1	P0011
⑦		4	P0053
⑧		4	G0067
⑨		9	W0092
⑩		2	W0398
⑪		1	G0012
⑫		4	B0015
⑬		1	M0026
⑭		1	M0027
⑮		1	M0011
⑯		1	G0047
⑰	Glass Door	1	G0077


ASSEMBLED RACK

 Net weight: 54 lbs.
(24.5 kg)

 Dimensions
Unit : inch (mm)

	1	2
A	14-7/8" (378)	19-5/16" (490)
B	12-15/16" (329)	8-9/16" (217)


STEP 1

STEP 2


STEP 3




STEP 4

WOODGRAIN SURFACES UP AND FORWARD




STEP 5




CONTINUED NEXT PAGE

ASSEMBLY INSTRUCTIONS

STEP 6



STEP 7



MODEL: SRC-502 © /552 ©

ITEM	DESCRIPTION	QTY	PART NO.		ITEM	DESCRIPTION	QTY	PART NO.
			SRC-502 ©	SRC-552 ©				
A	LEFT SIDE PANEL	1	XW0496	XW0510	M	MAGNET CATCH	1	P0011
B	BOTTOM BOARD	1	XW0311	XW0311	N	SHELF PIN	4	P0053
C	RIGHT SIDE PANEL	1	XW0495	XW0509	O	RUBBER SPACER	4	G0067
D	KICK PLATE	1	XW0497	XW0511	P	WOOD DOWEL	9	W0092
E	TOP BOARD	1	XW0494	XW0508	Q	WOOD DOWEL	2	W0398
F	BACK BOARD	1	XW0492	XW0492	R	GLUE	1	G0012
G	SHELF A	1	XW0431	XW0431	S	SHELF PIN	4	B0015
H	SHELF B	1	XW0310	XW0310	T	UPPER HINGE	1	M0026
I	CONFIRMAT SCREW	4	S0033	S0035	U	LOWER HINGE	1	M0027
J	SCREW	16	S0034	S0034	V	CATCH PLATE	1	M0011
K	ALLEN WRENCH	1	M0018	M0018	W	CATCH PLATE PAD	1	G0047
L	HINGE INSERT	2	P0054	P0054	X	GLASS DOOR	1	G0077

If any parts are MISSING or DAMAGED in this package, circle the item(s) needed on the parts list. Print your name, address, and phone number in the area to the left and mail to:

TOCABI/AMERICA,
9375 Custom House
Plaza Road, Suite 1
San Ysidro, CA 92173,
or call (619)-661-6136.